




## START



**EN** - Wheel assembly  
**IT** - Montaggio ruote  
**DE** - Radmontage  
**FR** - Assemblage des roues  
**ES** - Montaje de rueda  
**PT** - Montagem da roda




**EN** - Oil cap replacement  
**IT** - Sostituzione tappo olio  
**DE** - Ölkappenaustausch  
**FR** - Remplacement du bouchon d'huile  
**ES** - Sustitución de tapón de aceite  
**PT** - Substituição de tampa de óleo




**EN** - Positioning  
**IT** - Posizionamento  
**DE** - Platzierung  
**FR** - Positionnement  
**ES** - Posicionamiento  
**PT** - Localização


50 cm




**EN** - Electrical connection  
**IT** - Collegamento elettrico  
**DE** - Elektrischer Anschluss  
**FR** - Connexion électrique  
**ES** - Conexión eléctrica  
**PT** - Conexão elétrica




**EN** - Switch on  
**IT** - Accensione  
**DE** - Einschalten  
**FR** - Mise en route  
**ES** - Arranque  
**PT** - Ignição




**EN** - Filling tank  
**IT** - Riempimento serbatoio  
**DE** - Füllgrad der Behälter  
**FR** - Remplissage du réservoir  
**ES** - Llenado del depósito  
**PT** - Enchimento do reservatório



**EN** - Pipe connection  
**IT** - Attacco tubo  
**DE** - Schlauch-Anschluss  
**FR** - Connexion du tuyau  
**ES** - Conexión de anguera  
**PT** - Conexão de tubo




**EN** - Pressure regulation  
**IT** - Regolazione di pressione  
**DE** - Druckregulung  
**FR** - Réglage de la pression  
**ES** - Regulación de presión  
**PT** - Regulação de pressão




**EN** - Shutdown  
**IT** - Spegnimento  
**DE** - Stilllegung  
**FR** - Arrêt  
**ES** - Apagado  
**PT** - Encerramento

## BEFORE MAINTENANCE




**EN** - Electrical disconnection  
**IT** - Scollegamento elettrico  
**DE** - Elektrische Trennung  
**FR** - Déconnexion électrique  
**ES** - Desconexión eléctrica  
**PT** - Desconexão elétrica





**EN** - Safety precaution  
**IT** - Precauzioni di sicurezza  
**FR** - Instructions de sécurité  
**DE** - Sicherheitsvorkehrung  
**ES** - Precauciones de seguridad  
**PT** - Precaução de segurança


## OIL CHANGE





**EN** - Oil change  
**IT** - Cambio olio  
**DE** - Ölwechsel  
**FR** - Changement d'huile  
**ES** - Cambio de aceite  
**PT** - Mudança de óleo





**EN** - Purge inlet  
**IT** - Apertura spurgo  
**DE** - Entlüftungsoffnung  
**FR** - Ouvre de la vidange  
**ES** - Apertura purgado  
**PT** - Entrada da purga



**EN** - Oil closure  
**IT** - Chiusura olio  
**DE** - Överschluss  
**FR** - Fermeture  
**ES** - Cierre purgado  
**PT** - Fechamento de óleo



**EN** - Level control  
**IT** - Controllo livello  
**DE** - Füllstandskontrolle  
**FR** - Contrôle du niveau  
**ES** - Control de nivel  
**PT** - Controle de nivel



Please check the user manual for full instructions - Prior to any operation read the safety instructions

The images are for illustrative purpose only / Le immagini sono puramente indicative / Die Bilder sind rein indikativ / Les images sont purement indicatives / Las imágenes son puramente indicativas



Please check the user manual for full instructions - Prior to any operation read the safety instructions

The images are for illustrative purpose only / Le immagini sono puramente indicative / Die Bilder sind rein indikativ / Les images sont purement indicatives / Las imágenes son puramente indicativas